
# **SAFEMASTER Emergency Stop Module BG 5925**





- · According to
  - Performance Level (PL) e and category 4 to EN ISO 13849-1: 2008
  - SIL Claimed Level (SIL CL) 3 to IEC/EN 62061
- Safety Integrity Level (SIL) 3 to IEC/EN 61508
- Output: max. 3 NO contacts, see contacts Single and 2-channel operation
- Line fault detection on On-button
- Manual restart or automatic restart, switch S2
- With or without cross fault monitoring in the E-stop loop, switch S1
- LED indicator for channel 1 and 2 and Power
- Removable terminal strips
- Wire connection: also 2 x 1.5 mm<sup>2</sup> stranded ferruled (isolated), DIN 46 228-1/-2/-3/-4 or 2 x 2.5 mm<sup>2</sup> stranded ferruled DIN 46 228-1/-2/-3
- Width 22.5 mm

## **Function Diagram**



# Approvals and Marking



\* see variants

### **Applications**

Protection of people and machines


- Emergency stop circuits on machines
- Monitoring of safety gates

### Indicators

BG 5925.02

LED Power: on when supply connected LED K1/K2: on when relay K1/K2 energized


# **Block Diagram**



# **Connection Terminals**


Terminal designation	Signal designation
A1+	+ / L
A2	- / N
S12, S22, S33, S34	Inputs
S11, S21	Outputs
13, 14, 23, 24, 33, 34	Forcibly guided NO contacts for release circuit
21, 22, 31, 32	Forcibly guided indicator output

# **Circuit Diagrams**





S33 S34



13 A2 S2 32 M7387 b

A1 S33 S34

24 33

34

M7389 b

13

IS11

14


K1 [


A2

13 21 S11 14 M7388 b

BG 5925.16 BG 5925.22

#### Unit programming





	S1	S2	
	available in unti		Function
BG 5925	yes	yes	
BG 5925/101	yes	yes	
BG 5925/102	no	no	automatic + without
BG 5925/103	no	no	manual + with
BG 5925/104	no	no	automatic + with
BG 5925/105	no	yes	without
BG 5925/106	no	yes	with

Disconnect unit before setting of S1 Drawing shows setting at the state of delivery

### Notes

Line fault detection on On-button:

The line fault detection is only active when S12 and S22 are switched simultaneously. If The On-button is closed before S12, S22 is connected to voltage (also when line fault across On-Button), the output contacts will not close. A line fault across the On-button which occurred after activation of the relay, will be detected with the next activation and the output contacts will not close. If a line fault occurs after the voltage has been connected to S12, S22, the unit will be activated because this line fault is similar to the normal On-function. The gold plated contacts of the BG 5925 mean that this module is also suitable for switching small loads of 1 mVA - 7 VA, 1 mW - 7 W in the range 0.1 - 60 V, 1 - 300 mA. The contacts also permit the maximum switching current. However since the gold plating will be burnt off at this current level, the device is no longer suitable for switching small loads after this (not for variant BG 5925.22/102).

The terminal S21 permits the operation of the device in IT-systems with insulation monitoring, serves as a reference point for testing the control voltage and is used to connect the E-stop loop when cross fault monitoring is selected.

Connecting the terminal S21 to the protective ground bridges the internal short-circuit protection of Line A2 (-). The short-circuit protection of line A1 (+) remains active.

To alter the functions automatic start - manual start and with or without cross fault monitoring, the switches S1 and S2 are used. These are located behind the front cover (see unit programming).

The setting with or without cross fault monitoring on E-stop buttons is made with S1. S2 is used to change between automatic an manual restart. On automatic start also the terminals S33 - S34 have to be linked. For connection please see application examples.

### **ATTENTION - AUTOMATIC START!**



According to IEC/EN 60 204-1 part 9.2.5.4.2 and 10.8.3 it is not allowed to restart automatically after emergency stop. Therefore the machine control has to disable the automatic start after emergency stop.

#### **Technical Data**

#### Input circuit

Nominal Voltage U<sub>N</sub>: DC 24 V, AC/DC 24 V

 $\begin{array}{ccc} & & \text{AC 230 V with variant /105 and /106} \\ \textbf{Voltage range} & & \text{DC} & \text{AC/DC} \\ \text{at 10% residual ripple:} & & 0.9 \dots 1.1 \ \text{U}_{\text{N}} & & 0.95 \dots 1.1 \ \text{U}_{\text{N}} \\ \end{array}$ 

at 48% Rresidual ripple:  $0.9 ... 1.1 U_{N} = 0.95 ... 1.1 U_{N} = 0.8 ... 1.1 U_{N} = 0.8 ... 1.1 U_{N} = 0.85 .$ 

Nominal consumption: DC approx. 2 W Min. Off-time: 250 ms

Control voltage on S11: DC 23 V at U<sub>N</sub>

**S12, S22:** 40 mA at  $U_N$  Min. voltage between

terminals S12, S22 and S21: DC 21 V when relay activated

 $\begin{array}{ccc} & & \text{and } \mathsf{U_N} \text{ on A1 - A2} \\ \textbf{Short-circuit protection:} & & \text{Internal PTC} \\ \textbf{Overvoltage protection:} & & \text{Internal VDR} \\ \end{array}$ 

#### Outpu

 Contacts

 BG 5925.02:
 2 NO contacts

 BG 5925.03:
 3 NO contact

 BG 5925.16:
 1 NO, 1 NC contact

 BG 5925.22:
 2 NO, 1 NC contact

The NO contacts are safety contacts.

ATTENTION! The NC contacts 21-22
or 31-32 can only be used for

monitoring.

Operate delay typ. at U<sub>N</sub>:

Manual start: 40 ms automatic start: 250 ms BG 5925.\_\_/101: 100 ms

Release delay typ. at U<sub>N</sub>: Disconnecting the supply:

Disconnecting the supply: 50 ms
Disconnecting S12, S22: 15 ms
Contact type: forcibly guided
Nominal output voltage: AC 250 V

DC: see limit curve for arc-free operation

Switching of low loads:  $\geq 100 \text{ mV}$  (contact 5  $\mu$  Au)  $\geq 1 \text{ mA}$ 

(contact AgNi)  $\geq$  10 mA / DC 24 V

Thermal current I<sub>th</sub>: on 1 contact path:

n 1 contact path: " max. 5 A see current limit curve

Switching capacity to AC 15:

NO contacts: 3 A / AC 230 V IEC/EN 60 947-5-1 NC contacts: 2 A / AC 230 V IEC/EN 60 947-5-1 to DC 13:

NO contacts: 1 A / DC 24 V NC contacts: 1 A / DC 24 V

Electrical contact life to AC 15 at 2 A, AC 230 V:  $10^5$  switching cycles IEC/EN 60 947-5-1 to DC 13 at 1 A, DC 24 V:  $> 1.5 \times 10^5$  switching cycles

Permissible operating frequency:

max. 1 200 operating cycles / h

IFC/FN 60 947-5-1

IEC/EN 60 947-5-1

Short circuit strength
max. fuse rating:
line circuit breaker:

6 A general-purpose IEC/EN 60 947-5-1
C 8 A

**Mechanical life:** 10 x 10<sup>6</sup> switching cycles

2 13.03.14 en / 424

## **Technical Data**

#### **General Data**

Operating mode: Continuous operation

Temperature range

operation: - 15 ... + 55 °C - 25 ... + 85 °C storage: altitude: < 2.000 m

Clearance and creepage distances

rated impuls voltage /

pollution degree: 4 kV / 2 (basis insulation) IEC 60 664-1

**EMC** Electrostatic discharge:

IEC/EN 61 000-4-2 8 kV (air) HF irradiation: 10 V / m IEC/EN 61 000-4-3 2 kV Fast transients: IEC/EN 61 000-4-4

Surge voltages between

wires for power supply: 1 kV IEC/EN 61 000-4-5 between wire and ground: 2 kV IEC/EN 61 000-4-5 Interference suppression: Limit value class B EN 55 011

Degree of protection

Housing: IP 40 IFC/FN 60 529 IP 20 Terminals: IEC/EN 60 529

Housing: Thermoplastic with V0 behaviour according to UL subject 94

Vibration resistance: Amplitude 0.35 mm IEC/EN 60 068-2-6

frequency 10 ... 55 Hz

15 / 055 / 04 IEC/EN 60 068-1 Climate resistance:

Terminal designation: EN 50 005 Wire connection: 1 x 4 mm<sup>2</sup> solid or

1 x 2.5 mm<sup>2</sup> stranded ferruled (isolated)

2 x 1.5 mm<sup>2</sup> stranded ferruled (isolated) DIN 46 228-1/-2/-3/-4 or

a (year)

2 x 2.5 mm<sup>2</sup> stranded ferruled DIN 46 228-1/-2/-3

Box terminal with wire protection, Wire fixing:

removable terminal strips

DIN rail IEC/EN 60 715 Mounting:

Weight: 220 g

**Dimensions** 

Width x height x depth: 22.5 x 84 x 121 mm

#### Safety Related Data

Values according to EN ISO 13849-1:

Category: 4 PL: e MTTF. 236.3

DC / DC avg: 99.0 d<sub>op</sub>: h<sub>op</sub>: 365 d/a (days/year) 24 h/d (hours/day) 3600 s/Zyklus t<sub>Zyklus</sub>: **≙** 1 /h (hour)

Values according to IEC/EN 62061 / IEC/EN 61508:

IEC/EN 62061 SIL CL: 3 SIL: 3 IEC/EN 61508 HFT: DC / DC<sub>avg</sub>: 99.0 % % SFF: 99.7 PFH<sub>D</sub>: 1.97E-10  $h^{-1}$ T₁: 20 a (year)

\*) HFT = Hardware-Failure Tolerance

The values stated above are valid for the standard type. Safety data for other variants are available on request. Info

The safety relevant data of the complete system has to be determined by the manufacturer of the system.

#### **UL-Data**

The safety functions were not evaluated by UL. Listing is accomplished according to requirements of Standard UL 508, "general use applications"

Nominal voltage U<sub>N</sub>:

BG 5925, /101, /102, /103, /104: DC 24 V

AC/DC 24 V

Ambient temperature: -15 ... +55°C

Switching capacity:

Ambient temperature 45°C Pilot duty B300

5A 250 Vac Resistive 5A 24Vdc Resistive or G.P.

Ambient temperature 55°C: Pilot duty B300

4A 250Vac Resistive 4A 24Vdc Resistive or G.P.

Wire connection: 60°C / 75°C copper conductors only

AWG 20 - 12 Sol Torque 0.8 Nm AWG 20 - 14 Str Torque 0.8 Nm



Technical data that is not stated in the UL-Data, can be found in the technical data section.

#### **CSA-Data**

Nominal voltage U<sub>N</sub>:

BG 5925/113, /114: DC 24 V AC/DC 24 V

Ambient temperature: -15 ... +55°C

Switching capacity: 5A 230Vac

60°C / 75°C copper conductors only Wire connection:

AWG 20 - 12 Sol Torque 0.8 Nm AWG 20 - 14 Str Torque 0.8 Nm



Technical data that is not stated in the UL-Data, can be found in the technical data section.

# **Standard Type**

BG 5925.03/61 AC/DC 24 V

Article number: 0049169 Output: 3 NO contacts Nominal voltage U,: AC / DC 24 V Width: 22.5 mm

## **Variants**

BG 5925.\_\_/60: CSA-approval **UL-approval** BG 5925.\_ \_/61:

BG 5925.\_\_/101: E-stop with fast automatic start without line fault

detection on the ON-button

Automatic-restart, without crossfault monitoring BG 5925.\_\_/102: BG 5925.02/103: Manual restart, with crossfault monitoring for DC 24 V

Switching capacity to AC 15: 5 A / 230 V Contact fuse 6 A fast / 4 A slow

without internal switches S1 and S2

BG 5925.02/104: Automatic restart, with cross fault monitoring for

DC 24 V

Switching capacity to AC 15: 5 A / 230 V Contact fuse 6 A fast / 4 A slow without internal switches S1 and S2

BG 5925.\_\_/105: With switch S1 and without crossfault monitoring


for AC 230 V

BG 5925.\_\_/106: With switch S2 and with crossfault monitoring

for AC 230 V


### Ordering example for variants

3




13.03.14 en / 424

## Characteristics




### Arc limit curve under resistive load




## Quadratic total current limit curve

electric life DC13 24V DC /  $t_{\mbox{on}}$  0,4s;  $t_{\mbox{off}}$  9,6s 2 contacts in series



Contact service life

### **Application Examples**




Single channel emergency stop circuit. This circuit does not have any redundancy in the emergency-stop control circuit.

Note: Refer to "Unit programming"!

Switches in pos.: S1 no cross fault detection

S2 manual start

Suited up to SIL2, Performance Level d, Cat. 3




Contact reinforcement by external contactors controlled by one contact path.

Note: Refer to "Unit programming"!

Switches in pos.: S1 no cross fault detection

S2 manual start

Suited up to SIL3, Performance Level e, Cat. 4



Contact reinforcement by external contactors, 2-channel controlled. The output contacts can be reinforced by external contactors with forcibly guided contacts for switching currents > 8 A.


Functioning of the external contactors is monitored by looping the NC contacts into the closing circuit (terminals S33-S34).

Note: Refer to "Unit programming"!

Switches in pos.: S1 no cross fault detection

S2 manual start

Suited up to SIL3, Performance Level e, Cat. 4




2-channel emergency stop circuit without cross fault monitoring.

Note: Refer to "Unit programming"!

Switches in pos.: S1 no cross fault detection

S2 manual start

Suited up to SIL3, Performance Level e, Cat. 4




2-channel safety gate monitoring.

Note: Refer to "Unit programming"!

Switches in pos.: S1 no cross fault detection

S2 manual start

Suited up to SIL3, Performance Level e, Cat. 4



2-channel emergency stop circuit with cross fault detection

Note: Refer to "Unit programming"!

Switches in pos.: S1 cross fault detection

S2 manual start

Suited up to SIL3, Performance Level e, Cat. 4

5 13.03.14 en / 424

E. DOLD & SÖHNE KG • D-78114 Furtwang	<b>en</b> • PO Box 1251 • Telephone (+49) 77	723/654-0 • Telefax (+49) 77 23/654-356	